



TRU TRAK

Self Install

FMB920 Commercial Tracker

INSTALLING HARD WIRED GPS TRACKERS

The wiring location for your vehicle would be dependent upon each individual vehicle type and your choice of installation location.

As a general rule, you will only need to use the Red, Yellow and Black Wires for installing the device – for assistance, it is recommended that you check on <http://www.commandocaralarms.com/wiringsearch.asp> searching for the make and model of your specific vehicle.

****You will need to ensure all wiring is securely connected.****

For your Constant Power wire, you will need to connect the device's **RED** wire
For your Ignition Source, you will need to connect the device's **YELLOW** wire
For your Ground Wire which is **BLACK**, this can be installed anywhere on your vehicle that has bare metal.

It is essential that the device and all wires are attached securely to remain in place. The unit **MUST** be installed with the black label side facing to the sky/up to receive optimum signal for tracking your vehicles.

If you are in any way not confident in installing these devices yourself, it is recommended that you take it to your local engineer/mechanic for installation – if you would like to use our engineering service, please feel free to call us to arrange (this will be at a charge of £45+vat per vehicle install).

**Once installed take a short 5 minute drive then call 01473 794420
and we will ensure it is operating correctly
and associate your registration.**

SALES@TRUTRAK.CO.UK | ACCOUNTS@TRUTRAK.CO.UK | SUPPORT@TRUTRAK.CO.UK | BOOKINGS@TRUTRAK.CO.UK

UNIT 7, DENCORA HOUSE, WHITEHOUSE ROAD, IPSWICH, SUFFOLK, IP1 5LT